User Guide

StyleView® Telepresence Kit

with Dual LCD



NOTE: This kit is intended to be attached to a cart with single LCD pivot and one drawer.

ENGLISH

Safety 2
Features & Specifications 3
Tools Needed & Components 4
Drawer ..... 5 - 9
CPU Holder ..... 10 - 12
Camera Shelf ..... 13 - 15
Dual Display Crossbar ..... 16 - 17
Adjustment 18
Maintenance & Safety ..... 19 - 20

For the latest User Installation Guide please visit: www.ergotron.com

User's Guide - English
Guía del usuario - Español
Manuel de l'utilisateur - Français
Gebruikersgids - Deutsch
Benutzerhandbuch - Nederlands
Guida per l'utente - Italiano
Användarhandbok - svenska
ユーザーガイド : 日本語
用户指南 ：汉语

www.ergotron.com
USA **1-800-888-8458**
Europe **+31 (0)33-45 45 600**
China **86-769-86018920**

888-97-334-G-00 rev. A • 09/13

Hazard Symbols Review

These symbols alert users of a safety condition that demands attention. All users should be able to recognize and understand the significance of the following Safety Hazards if encountered on the product or within the documentation. Children who are not able to recognize and respond appropriately to Safety Alerts should not use this product without adult supervision!

Symbol	Signal Word/ Color	Level of Hazard
	DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
	WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
	CAUTION	Used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.
	INSTRUCTIONS	Follow operating instructions.
	INSTRUCTIONS	Follow operating instructions.
	POWER	"ON" / "OFF" (push-push) NOTE: Each position "ON" / "OFF" is a stable position.

Safety



CAUTION: Close worksurface before opening drawers. Open only one drawer at a time. Do Not push cart when drawers or worksurface are open. Failure to follow these instructions may cause the cart to be unstable.

WARNING
Ø14mm (9/16")
IMPACT HAZARD!
MOVING PARTS CAN CRUSH AND CUT.
Minimize Lift Tension BEFORE:
· Removing Mounted Equipment.
· Shipping Cart
· Storing Cart
To Minimize Lift Tension
1. Lower worksurface to lowest position.
2. Turn adjustment nut at top of riser counterclockwise until it stops (Adjustment may require 40-60 revolutions).
Failure to heed this warning may result in serious personal injury or property damage!
For More information and instructions refer to product guide at http://4support.ergotron.com or contact Ergotron Customer Care at 1-800-888-8458.
822-052

Important! You will need to adjust this product after installation is complete. Make sure all your equipment is properly installed on the product before attempting adjustments. This product should move smoothly and easily through the full range of motion and stay where you set it. If movements are too easy or difficult or if product does not stay in desired positions, follow the adjustment instructions to create smooth and easy movements. Depending on your product and the adjustment, it may take many turns to notice a difference. Any time equipment is added or removed from this product, resulting in a change in the weight of the mounted load, you should repeat these adjustment steps to ensure safe and optimum operation.

ENGLISH

Features & Specifications





Weight Capacity

6-10 lbs (2.72-4.5 kg) **A+B** =12-20 lbs (5.4-9.1 kg)

0 lbs (0 kg) Open Worksurface
<5 lbs (2.3 kg) Closed Worksurface
<13 lbs (5.9 kg) CPU Compartment





SV41 Carts:



*Combined LCD and CPU Compartment weight: <27 lbs (12.2 kg).

CAUTION:
If the combined LCD and CPU weight is greater than 27 lbs (12.2 kg) then the CPU must be mounted to the rear of the cart using the Universal CPU Holder accessory (ordered separately).

ENGLISH

Tools Needed







Components

	A	B	C	D	E
1	1x	1x 	1x 	1x 	1x M4 x 6mm
2	1x 1x				2x  M4 x 14mm
3					4x  M4 x 25mm

	A	B	C	D
1	1x 	1x 	1x 2x  M4 x 12mm	1x 1x  M3 x 22mm

	A	B	C	D	E	F
1	1x 	1x 	2x  10-24 x 1/2"	2x  M5 x 10mm 2x 	12x 	2x

	A	B	C	D
1	1x 	2x 	2x  M6 x 18mm	2x M4 x 5mm
2	1x 	1x 	1x  M5 x 55mm	1x  4mm 1x 3mm
3	4x M3 x 6mm 4x 2x 	1x  1x 1x 	8x M4 x 10mm 8x 	2x  M6 x 28mm 2x M4 x 8mm
4	4x	4x 2x	8x M5 x 10mm	1x M4 x 8mm



1 Attach the Travel Stop bracket to the lift engine to keep the drawer from hitting the base.

1x



M3 x 22mm

a



b



2 Slide the drawer only half way onto the bottom tracks of the existing top drawer.



ENGLISH



3



Remove the top cover on the top drawer and route the cable attached to the bottom drawer up into the control panel on the top drawer.

Powered Carts



Non-Powered Carts



4

Slide the drawer completely onto the bottom tracks of the top drawer.



ENGLISH



5 Replace the top cover on the top drawer.





6 Remove the top drawer(s).





7 Secure the bottom drawer by attaching the two screws.



2x



M4 x 12mm

8 Replace the top drawer(s).





ENGLISH



9 On Powered Carts only, reset drawer power so keypad will recognize added drawer. NOTE: This step is not needed on Non-Powered Carts.

a Turn off all mounted equipment.



b Disconnect Power System from power source.



c Turn power system off by holding down the AC Outlet Power button for 1 - 3 seconds. Power light will shut off.

d Remove front base cover.



e Unplug drawer power cable and then plug it back in to reset.



f Replace front base cover.



ENGLISH

888-97-334-G-00 rev. A • 09/13



11 Insert divider.





1 a





b





c



ENGLISH

2 a

2x

M5 x 10mm





b



c



3 a

4x





b

8x







4 a



b

2x



ENGLISH

5 a



b





6





7

a





b



c



d



ENGLISH

888-97-334-G-00 rev. A • 09/13



1



2 a

2x M3 x 6mm

2x 2x



b

1x 1x

1x

M5 x 55mm



3

1x M4 x 8mm



WARNING
AVERTISSEMENT
1.
2.
3.
IMPACT HAZARD!
MOVING PARTS CAN CRUSH AND CUT.
Failure to heed this warning may result in serious personal injury or property damage!
Raise monitor to top of vertical adjustment BEFORE removing.
DO NOT remove Stop Screw without monitor attached. Doing so will cause monitor pivot to shoot up rapidly and may cause personal injury.
DANGER D'IMPACT !
LES PARTIES EN MOUVEMENT PEUVENT ÉCRASER ET COUPER.
Il existe un risque de blessure corporelle ou d'endommagement matériel en cas de non respect de cet avertissement.
Élevez l'écran au plus haut de l'ajustement vertical AVANT de le retirer.
NE retirez PAS la vis d'arrêt avant que l'écran soit fixé.
Dans un tel cas, le pivot d'écran se relèverait rapidement et cela pourrait engendrer des blessures.
www.ergotron.com
826-502

ENGLISH



4



5



6



ENGLISH

888-97-334-G-00 rev. A • 09/13



7







8



9



10





11



ENGLISH



Max weight: 2 lbs (1 kg)

NOTE: camera is supplied by customer.

1

1x M4 x 6mm



If your monitor has recessed mounting holes, you need to add the provided spacer between the monitor and the mounting plate.



2

a



b

2x M4 x 14mm



c



d

2x M4 x 14mm



ENGLISH

888-97-334-G-00 rev. A • 09/13



3

3 Mounting Options



a



b



a



b



c



d



ENGLISH

Adjustment Step

It is important that you adjust this product according to the weight of the mounted equipment as described in the following steps. Any time equipment is added or removed from this product, resulting in a change in the weight of the mounted load, you should repeat these adjustment steps to ensure safe and optimum operation.
Adjustments should move smoothly and easily through the full range of motion and stay where you set it. If adjustments are difficult and do not stay in the desired position, follow the instructions to loosen or tighten the tension to create a smooth, easy adjustment motion. Depending on your product and the adjustment, it may take several turns to notice a difference.

Lift – Up and down



Release Brake to move riser.



a

Follow these instructions to tighten or loosen tension.

1



2



NOTE: Adjustment may require 40 - 60 revolutions.

3



+ LB kg

Increase Lift Strength

If the mounted weight is too heavy or this product does not stay up when raised, then you'll need to increase Lift Strength:

– LB kg

Decrease Lift Strength

If the mounted weight is too light or this product does not stay down when lowered, then you'll need to decrease Lift Strength:

b

Lift – Up and down



Follow these instructions to tighten or loosen tension.





ENGLISH

Guidance and Manufacturer's Declaration – Electromagnetic Emissions		
Ergotron's Medical Grade Power Strip is intended for use in the electromagnetic environment specified below. The customer or the user of the Medical Grade Power Strip should assure that it is used in such an environment.		
Emissions Test	**Compliance**	**Electromagnetic environment – guidance**
RF Emissions CISPR 11	Group 1	Ergotron's Medical Grade Power Strip does not use RF energy for its internal function. Therefore, its RF emissions are very low and unlikely to cause any interference in nearby electronic equipment.
RF Emissions CISPR 11	Class B	Ergotron's Medical Grade Power Strip is suitable for use in all establishments other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.
Harmonic Emissions IEC 61000-3-2	Class B	
Voltage fluctuations/ flicker emissions IEC 61000-3-3	Complies	

Guidance and Manufacturer's Declaration – Electromagnetic Immunity			
Ergotron's Medical Grade Power Strip is intended for use in the electromagnetic environment specified below. The customer or the user of the Medical Grade Power Strip should assure that it is used in such an environment.			
Immunity Test	**IEC 60601 Test Level**	**Compliance Level**	**Electromagnetic environment - guidance**
Electrostatic Discharge (ESD) IEC 61000-4-2	±6 kV contact ±8 kV air	Complies	Floors should be wood, concrete, or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%
Electrical Fast Transient/Burst IEC 61000-4-3	±2 kV for power supply lines ±1 kV for input/output lines	Complies	Mains power quality should be that of a typical commercial or hospital environment.
Surge IEC 61000-4-5	±1 kV differential mode ±2 kV common mode	Complies	Mains power quality should be that of a typical commercial or hospital environment
Voltage Dips, short interruptions, and voltage variations on power supply input lines IEC 61000-4-11	<5% U_T (>95% dip in U_T) for 0.5 cycle 40% U_T (60% dip in U_T) for 5 cycles 70% U_T (30% dip in U_T) for 25 cycles <5% U_T (>95% dip in U_T) for 5 seconds	Complies	Mains power quality should be that of a typical commercial or hospital environment.
Power Frequency (50/60 Hz) Magnetic Field IEC 61000-4-8	3 A/m	Complies	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.
Note: U_T is the AC mains voltage prior to application of the test level			

Safety Alerts Associated with this Product

The following Warnings/Cautions appear in this reference guide or on the Power Strip. NOTE: Failure to adhere to these guidelines may result in equipment damage or personal injury.

⚠ Cleaning and Maintenance

The following procedures are not guaranteed to control infection. The hospital infection control administrator or epidemiologist should be consulted regarding cleaning procedures and processes.

⚠ To avoid risk of electric shock, do not expose electrical components to water, cleaning solutions or other potentially corrosive liquids or substances.

⚠ Do not immerse Power Strip or Power Strip components in liquid or allow liquids to flow into the Power Strip. Wipe all cleaners off surface immediately using a damp cloth. Thoroughly dry surface after cleaning.

⚠ Do not use flammable cleaners on Power Strip surfaces due to close proximity of electrical power and equipment.

All paints and plastic Power Strip components will withstand cleaning by most commonly used, diluted, non-abrasive solutions such as quaternary ammonia compounds, ammonia enzyme cleaners, bleach or alcohol solutions.

- Pen and permanent and dry erase markers can be removed with 91% isopropyl alcohol and a soft cloth.
- Iodine stains can be removed with commonly used cleaners and a soft cloth.
- Never use steel wool or other abrasive materials that will damage the surface finish.

It is recommended that any cleaning solution be tested on a small, inconspicuous area to ensure surface is not harmed.

⚠ Adjustment, Service, Replacement - DO NOT attempt to adjust, service or replace any part of the Power Strip unless directed to do so through Ergotron-approved documentation (i.e. installation instructions). Only Ergotron, Inc. or an Ergotron-certified entity may adjust, service or replace Power Strip components. If any component on the Power Strip is missing or damaged, the Power Strip must not be used, contact Ergotron Customer Care immediately to request a replacement part.

⚠ Cables - Keep cables neatly organized (the provided Strain Relief and Hook are designed for this purpose). Excess cables should be routed away from moving components with cable clips or ties. Review Cable Routing section of this guide, or contact Ergotron Customer Care for more information.

⚠ Customer Equipment- Do not connect electrical equipment beyond rated ....

⚠ Customer Equipment- Only cart-mounted electrical equipment should be connected to Power Strip.

⚠ The polarized cord on this Power Strip is Hospital Grade Only. Grounding reliability can only be achieved when the equipment is connected to an equivalent receptacle marked "Hospital Only" or "Hospital Grade".

⚠ The device is not suitable for use in the presence of a flammable anaesthetic mixture with air or with oxygen or nitrous oxide.

ENGLISH

For service and warranty visit www.ergotron.com

For local customer care phone numbers visit: http://contact.ergotron.com

© 2013 Ergotron, Inc.
All rights reserved.

While Ergotron, Inc. makes every effort to provide accurate and complete information on the installation and use of its products, it will not be held liable for any editorial errors or omissions (including those made in the process of translation from English to another language), or for incidental, special or consequential damages of any nature resulting from furnishing this instruction and performance of equipment in connection with this instruction. Ergotron, Inc. reserves the right to make changes in the product design and/or product documentation without notification to its users. For the most current product information, or to know if this document is available in languages other than those herein, please contact Ergotron. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of Ergotron, Inc.,1181 Trapp Road, Eagan, Minnesota, 55121, USA Patents Pending and Patented U.S. & Foreign. Ergotron is a registered trademark of Ergotron, Inc.

Americas Sales and Corporate Headquarters
St. Paul, MN USA
(800) 888-8458
+1-651-681-7600
www.ergotron.com
sales@ergotron.com

EMEA Sales
Amersfoort, The Netherlands
+31 33 45 45 600
www.ergotron.com
info.eu@ergotron.com

APAC Sales
Tokyo, Japan
www.ergotron.com
apaccustomerservice@ergotron.com

Worldwide OEM Sales
www.ergotron.com
info.oem@ergotron.com